



Speedway Shelters Wood Base Foundation Assembly Instructions

Materials and tools needed:



Power drill & 2" woodscrews (28 ea.)



1.5 inch bolts & nuts (6 ea.), washers (12 ea.)



3/4 inch plywood- 2x4 Supports



Separate 2x4s approximately 20" apart from each other (20" centers).



Attach 2x4s to plywood using 2 inch woodscrews.



For best results apply a standard patio or deck sealer to waterproof.



Add Speedway Shelters floor for extra protection from moisture and dust.



Locate 2-each anchor holes on both sides of the frame assembly. Mark and drill the holes.



Secure the frame to plywood using 1.5" bolts, washers, and nuts.



Use the same 1.5: bolts, nuts, and washers to secure the anchor plate (2 holes).



Keeps water and dirt away and provides a clean, dry interior.



Completed base for your Speedway Shelter.